



Stewart & Heaton Clothing Co. Pty Ltd

As Trustee for the S&H Unit Trust. ACN 051 578 842 ABN 49 282 169 771

email: admin@shcc.com.au accounts@shcc.com.au

Website: www.shcc.com.au



Quality
ISO 9001

SAI GLOBAL

SIZING GUIDE FROM BODY MEASUREMENTS NSW RFS - T325 and J344

TROUSER - T325

SIZES REGULAR	67R	72R	77R	82R	87R	92R	97R	102R	107R	112R
To fit waist (cm)	67	72	77	82	87	92	97	102	107	112
Inleg*	72	73	74	75	76	77	78	79	80	81


SIZES STOUT	87S	92S	97S	102S	107S	112S	117S	122S	127S	132S
To fit waist (cm)	87	92	97	102	107	112	117	122	127	132
Inleg*	72	73	74	75	76	77	78	79	80	81

SIZES LONG	74L	79L	84L	89L	94L
To fit waist (cm)	74	79	84	89	94
Inleg*	78	79	80	81	82

JACKET - J344

SIZES	72	77	82	87	92	97	102	107	112	117	122	127	132
To fit chest (cm)	82	87	92	97	102	107	112	117	122	127	132	137	142

*Inleg is a finished garment measurement



How to MEASURE

- A Neck Measure around your neck where the top of the collar would fit.
- B Chest /Bust Measure around the chest/bust at the fullest point making sure to keep the tape level front and back.
- C Waist Measure around the waist at the natural waist line.
- D Hip Measure around hip at the widest part.
- E Inleg Measure from the crotch to the floor - no shoes.

When taking measurements you will need someone to help you and a tape measure.

The tape should be flat against the body taking care not to make it too tight.

Measurements should be take over undergarments not clothing

Measurements are a guide only. Variations may occur depending on style and fit of individual garments

As of 5/10/16